



Care and Maintenance Information

Cleaning Directions

It is recommended that you clean your toilet partitions regularly with clean, warm, soapy water using a cloth and wipe dry with a soft clean cloth.

For built up dirt, stains, paint etc on the laminate, please refer to the cleaning directions issued by The Laminex Group (attached).

Low Pressure Laminate

Do not use in high humidity or in wet areas such as saunas or showers. Do not hose down. Recommended to clean with a damp rag soaked in soapy water using a mild detergent.

High Pressure Laminate

May be used in wet areas such as saunas or showers with a marine ply core only. Recommended to clean with a damp rag soaked in soapy water using a mild detergent.

Compact Laminate

May be used in high humidity or in wet areas such as saunas or showers. Recommended for use when hose down cleaning required. Recommended to clean with a damp rag soaked in soapy water using a mild detergent.

Deco Metal Laminate

May be used in wet areas such as saunas or showers with a marine ply core only. Recommended to clean with a damp rag soaked in soapy water using a mild detergent. Please note this product is not scratch resistant and is easily scratched.

Caution

Do not use any abrasive cleaners, bleaches, scouring pads, wire wool, sandpaper or strong mineral acids on laminates or aluminium.

P O Box 51 964 Pakuranga Auckland 2140
27a Bowden Road
Mt Wellington Auckland 1060
Tel 09 273 1524
Fax 09 273 1525
Web www.kermac.co.nz